

Weight Indicator MODEL MSS



TABLE OF CONTENTS	PAGE
General	1
Key Function	1
Power Options	1
Setup Menu	2
Calibration	3
Counting Operation	3
Check-Weighing Operation	3
Error Messages	3
Specification	4
Warranty Information	4



Industrial Weighing Systems

9 Richmond St. Picton, ON Canada K0K 2T0

Ph: 613-786-0016 Cell: 613-921-0397 Fax: 613-476-5293

E-mail info@iwsystems.ca Website: www.iwsystems.ca




INSTRUCTION MANUAL

The MSS Digital Weight Indicator is designed for general weighing, counting and check-weighing applications. The main features of the MSS indicator are:

- Full front panel setup and calibration
- Easy to read large 1" (25.4 mm) LED Display
- Weighing Units selection lb, kg, Parts counting function
- RS-232 data Interface
- Supplies enough current for up to 4-350 ohm Load Cells
- Powered by AC/DC Adaptor or NICAD Rechargeable Battery
- Wall Mounting Bracket, Stainless Steel housing

GENERAL

Unpack and keep the carton for storing display and/or future transportation. In the carton you should find this instruction manual with: 1 MSS Indicator, 1 mounting bracket, 1 AC/DC Adaptor
Load cells are connected using the 5 position removable plug inside the enclosure



(-E) = - excitation (+E) = + excitation (SH) = Shield (-S) = - signal (+S) = + signal

KEY FUNCTIONS

- ON/OFF Turns the scale ON or OFF
- ZERO When in Gross sets Gross weight to zero if in tolerance band.
- UNITS Weighing unit conversion selection
- TARE Acquires the tare weight to 0 in either GROSS or NET mode.
- GROSS/NET Toggles between GROSS and NET weight only if tare have been acquired
- PRINT Sends data via RS232 serial port

POWER OPTIONS

Operating with the AC/DC adapter

Connect the adapter (input 110VAC-120VAC, 60 Hz output: 9VDC, 500mA) to the socket at the rear of the indicator and plug into the main AC supply. The LED at the top of the front display will be ON indicating power is present.

Operating with battery power

Rechargeable Battery (6VDC 1.2A) is inserted under the bracket inside the back cover. Connect the 2 wires from the circuit board to the battery, RED (=) Black (-).

A full charging cycle takes about 8 hours with the indicator turned off. The battery will reach full capacity providing about 20 hours of service after 3-5 full charging cycles. The power LED is RED when the battery is being charged and turns GREEN when charge is full.

A suitable Battery is available from Industrial Weighing Systems if not ordered with instrument.



SETUP MENU CHART

Front panel keys: **ZERO**, **UNITS**, **GROSS/NET** and **PRINT** are used for menu navigation.
TARE is used to enter the menu and to save selection.

- F1- CLK** Time set up (Hr:Min:Sec), Date [(D-M-Y), (Y-M-D), (M-D-Y) }
- F2-SLP** Battery save mode, 2 options and time interval
Mode 1=OFF (shut off if inactive for set time)
Mode 2= Standby (decimal at right digit is on, display returns when weight applied)
- SLP** NO (continuous display), 5,10, 15 (mode 1 or 2 after "X" minutes of stable weight)
- F3 KEY** Cn on/oFF (counting function on or off)
- F4 CHK** Check-weighing (after setting beep, set Lo then High limits, see page 3)
Beep -1 (no audible beep), beep-2 beep if in range, beep-3 beep outside range
- F5 INP** Display internal A/D counts
- F6 BAT** Reserved for adjusting DC power supply.
- F7 CAL** Press TARE key
When **Pn** appears press and release in sequence UNIT, ZERO, TARE
The following menu "P" will appear.

SETTING P5, P6 AND P7 MUST BE FOR THE UNITS (Lb or Kg) CURRENTLY ON THE DISPLAY

- P1 SP** A/D conversion speed (1, 2, 3, 4, 5) where 1 is fastest, 5 slowest.
- P2 AUT** Power on zero (0, 2, 5, 10, 20% of capacity) if in band zero is set on power up.
- P3 RAN** Manual zero band range (2, 4, 10, 20, 50, 100% capacity)
- P4 AZ** Auto zero track band (0, 0.5, 1, 3, 5 display divisions)
- P5 DEC** Decimal point position (0, 0.0, 0.00, 0.000, 0.0000)
- P6 CAP** Capacity (enter scale capacity using keypad)
- P7 INC** Display division or increment count (1, 2, 5, 10, 20)
- P8 CAL** Press TARE to enter calibration (calibration procedure page 3)
- P9 RS** RS-232 transmission (Aut-after each weight, Cot-continuous, Prt- use print button)
- P10 Kb** Keypad beep on/oFF, (beeps when keys pressed if on).



CALIBRATION

The span value for calibration is entered in the same units (Lb or Kg) currently on the display.

- 1: Turn the scale ON, when in the count down sequence press and release TARE.
- 2: When "Pn" appears, press and release in sequence UNIT, ZERO, TARE
- 3: "UnLoad" will be displayed, remove all weight to set Zero, Press TARE.
- 4: Enter/change the display to be the same as your calibration weight then press TARE.
- 5: "Load" appears in the display, apply calibration weights to scale and press TARE
- 6: Indicator will store calibration and return to weighing mode.

COUNTING OPERATION

* Activated when setup menu F3 KEY is ON.

1. Place a container on the scale and zero the indicator.
2. Press UNIT key until the display will show number of samples "P 5".
3. To change number of samples use PRINT and GROSS/NET keys.
4. Place the required number of samples into the container and press TARE key.
5. Wait till LED pcs will turn ON and the display will show number of pieces.
6. To return to the weighing mode press UNIT key.

CHECKWEIGHING OPERATION

- 1: During SETUP **F4 CHK**, if LO or/and HI values have been set to a value other than zero Check-weighing is ON.
- 2: LED Display segments status:

HI & LO segments	ON -load within the target range
HI	ON -load over the high target
LO	ON -load below the lower target
3. To have just one target LO or HI the second value in the set up menu **F4 CHK** has to be 0.
4. To stop the check-weighing set HI & LO values to 0 in set up menu **F4 CHK**.

RS-232

Baud Rate: 9600 Start Bit: 1 Data Bits: 8 Stop Bit: 1 Parity: None
Transmission only as per setting in **P9 RS**

ERROR MESSAGES

- The scale has been over loaded, remove excessive load,
If error continues, contact IWSystems
- Err 4 The ZERO setting range is less than the load applied.
Remove the load and try again, if error continues, contact IWSystems
- Err 6 The A/D is out of range, remove load from the scale.
Check load cells for faults, may be display, if error continues, contact IWSystems



Industrial Weighing Systems

E-mail info@iwsystems.ca Website: www.iwsystems.ca

SPECIFICATIONS

Display 6 Digit LED, 1" / 25.4mm digits
Weighing Units kg (kilograms), lb (pounds),
Internal Resolution Up to 500,000 counts
Display Resolution Up to 15,000 counts, selectable
Display Division 1,2,5,10,20 selectable
Decimal Point 0 to 4 places, selectable
Load Cell Excitation 5 VDC, 4 x 350 ohm Load Cells
Analog Input Range from 0.5 mV/V to 3.0 mV/V
Analog Sensitivity 0.5uV/grad min., 1 uV /grad recommended
Conversion Rate 20 samples/sec, nominal
Calibration Push button Software
Overload Limit 102% of selected Display Resolution
Tare Range To Capacity by Subtraction
Key Functions ON/OFF, ZERO, UNITS, TARE, GROSS/NET, PRINT
Operating Temperature -10° to +40°C (14° to 104°F)
Power AC/DC Adapter 9- 12VDC, 300- 500mA or Rechargeable Battery
Dimensions 8.2"x 5.5"x 2.9" Weight Approx.4.4lb/2kg

The specification may be changed without prior notice

LIMITED WARRANTY

The indicator is warranted to the original retail purchaser for a period of one year from the date of invoice against defects in materials and/or workmanship. During the warranty period we will repair or, at our option, replace free of charge the defective product, when used under normal conditions.

The product has to be returned to us, freight and insurance prepaid and securely packaged. Adjustment of any internal components by other than a factory authorized technician, or damage caused through negligence, abuse, accident, misuse, unreasonable use, improper service, force, foreign material inside of the product, exposure to corrosive materials or other causes not arising out of defects in material or workmanship voids warranty coverage. The manufacturer shall be the sole judge of all alleged non-conformities. Except as provided above, no other express or implied warranty is given by the manufacturer.

Manufacturers role and exclusive liability is limited to repair or replacement of such products. The manufacturer shall not be liable for any loss, inconvenience, or damage, including without limitation direct, indirect, special, incidental or consequential damages, resulting from use or inability to use a product, any breach of warranty or any act of omission of the manufacturer, its officers or agents. As warranty legislation varies from state to state and country to country, please refer to your local Dealer **Industrial Weighing Systems** for details.